




Ref	Part Number	Description	Ref	Part Number	Description
1	711-04585	Clevis Pin, .25 x 1.00	49	781-0788-0662	Tongue Tube — Gray
2	913-04036	Handle Valve Link	—	781-0788-0638	Tongue Tube — Red
3	914-0111	Cotter Pin, $\frac{3}{32}$ x 1.0	50	726-0214	Push Cap, $\frac{5}{8}$
4	918-04533	Valve (510)	51	732-0583	Compression Spring, .625 x 4.0
—	918-04534	Valve (550)	52	936-0116	Flat Washer, .635 x .93 x .06
—	918-0481A	Valve (570)	53	781-0690	Lock Rod
5	918-0769A	Hydraulic Cylinder	54	981-04040A-0637	Frame Assembly
6	720-04088	Grip	55	710-3085	Hex Screw, $\frac{3}{8}$ -16 x 3.50
7	727-04166	Hydraulic Hose, $\frac{3}{4}$ -16	56	712-04065	Flange Lock Nut, $\frac{3}{8}$ -16
8	737-0153	Hydro Fitting, 90 x $\frac{3}{4}$ x .75	57	710-0502A	Self-Tapping Screw, $\frac{3}{8}$ -16 x 1.250
9	737-0192	Hydro Fitting, 90 x $\frac{3}{4}$ x 1/2	58	736-3010	Flat Washer, .407 x .812 x .135
10	737-0238	Nipple Fitting, $\frac{1}{2}$ x 1.89	59	737-0348A	Vented Dipstick
11	747-04539	Hydraulic Valve Control	60	710-0376	Hex Screw, $\frac{5}{16}$ -18 x 1.00
12	710-0459A	Hex Screw, $\frac{3}{8}$ -24 x 1.50	61	710-3056	Hex Screw, $\frac{5}{16}$ -18 x 3.25
13	710-1018	Hex Screw, $\frac{1}{2}$ -20 x 2.75	62	712-04063	Flange Lock Nut, $\frac{5}{16}$ -18
14	710-1806	Hex Screw, $\frac{1}{2}$ -13 x 3.25	63	918-04127	Gear Pump
15	712-0711	Jam Nut, $\frac{3}{8}$ -24	64	719-0353	Coupling Shield
16	712-3022	Hex Lock Nut, $\frac{1}{2}$ -13	65	917-0891	Flex Coupling
17	912-3058	Hex Lock Nut, $\frac{1}{2}$ -20	—	710-1842	Set Screw, $\frac{1}{4}$ -20 x .38
18	719-0550A	Wedge	—	914-0122	Square Key, $\frac{3}{16}$ x .75
19	781-0351	Adjust Gibs, .625 x .625 x 2.00	—	718-04392	Coupling, .500
20	781-0790-0637	Back Plate	—	718-04395	Coupling, .875
21	710-0654A	Self-Tapping Screw, $\frac{3}{8}$ -16-1.000	—	735-04103	Spider Bushing
22	781-1048A-0662	Dislodger Bracket — Gray	66	727-04130	Inlet Hose
—	781-1048A-0638	Dislodger Bracket — Red	67	727-0502	Rubber Hydro Hose
23	723-0405	Oil Filter	68	737-0329	Hydraulic Fitting, 45 x $\frac{3}{4}$ x $\frac{3}{4}$
24	726-0132	Hose Clamp	69	737-04093	Inlet Filter
25	727-0443	Return Hose	70	781-0097-0637	Rear Coupling Support Bracket
26	737-0316	Filter Housing	71	710-0602	Hex Washer Screw, $\frac{5}{16}$ -18 x 1.000
27	737-0312	Adapter, $\frac{3}{4}$ -14	72	710-0650	Hex Washer Screw, $\frac{5}{16}$ -18 x .875
28	781-0526A	Hose Guard (510/570)	73	712-04063	Flange Lock Nut, $\frac{5}{16}$ -18
29	781-0538A	Hose Guard (510/570)	74	731-2496A	Fender (Black, 510/570)
30	711-1587	Clevis Pin, .625 x 4.0	—	731-2499A	Fender (Red, 550)
31	914-0470	Cotter Pin, $\frac{1}{8}$ x 1.25	75	736-0371	Flat Washer, .343 x .880 x .062
32	681-04071A-0637	Beam Assembly	76	634-0186	Complete Wheel Assembly
33	710-04484	Hex Washer Screw, $\frac{5}{16}$ -18 x .750	—	934-0180-0662	Wheel/Rim Assembly
34	781-04179-0637	Log Tray Bracket	—	921-0168	Dust Seal
35	781-04180-0637	Log Tray Bracket	—	941-0987	Roller Bearing
36	081-04030	Hitch Coupling Assembly	77	712-0359	Slotted Nut, 3/4-16
37	710-0521	Hex Screw, $\frac{3}{8}$ -16 x 3.00	78	714-0162	Cotter Pin, $\frac{5}{32}$ x 1.25
38	710-3085	Hex Screw, $\frac{3}{8}$ -16 x 3.50	79	914-0474	Hub Cap
39	911-0813	Clevis Pin, $\frac{5}{16}$ x 2.5	80	936-0351	Flat Washer, .760 x 1.50 x .030
40	712-04065	Flange Lock Nut, $\frac{3}{8}$ -16	81	625-0062	Light Assembly Kit (570)
41	713-0433A	Tow Chain	82	681-0164-0637	LH Light Bracket (570)
42	915-0120	Spiral Pin, $\frac{3}{16}$ x 1.00	83	912-3008	Jam Nut, $\frac{3}{8}$ -16 (570)
43	732-0194	Spring Pin	84	712-04063	Flange Lock Nut, $\frac{5}{16}$ -18 (570)
44	932-3127	Compression Spring, .66 x 1.8	85	781-1027A-0637	RH Light Bracket (570)
45	936-0185	Flat Washer, .375 x .738 x .063			
46	747-1261	Tongue Latch Rod			
47	781-1045-0662	Tongue Latch — Gray			
—	781-1045-0638	Tongue Latch — Red			
48	781-0789-0637	Jack Stand			

※ 薪割機のモデルによって異なります。リスト、図にあるすべてのパーツが標準で付いているわけではありません。